

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Колмна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://stm.nt-rt.ru> || sfj@nt-rt.ru

AQUA TRANSFER



DOUGH-MIXER DISTRIBUTOR

The dough-mixer distributor STM Aqua Transfer is an accessory designed to make it easy and automatic to serve up to 6 mixers with the same DOX or DOMIX STM.

Aqua Transfer offers a simple and intuitive interface from which you can select the mixer you want to serve, give the START to the water delivery or pause it using the STOP button.

MODEL	DESCRIPTION	POWER SUPPLY
AT EASY_2	Water distributor to serve 2 dough-mixers, with 1/2" S.V. and 16mm hydraulic connections. Compatible with DOX and DOMIX 25/30/45.	115V/230V
AT EASY_4	Water distributor to serve 4 dough-mixers, with 1/2" S.V. and 16mm hydraulic connections.	115V/230V

MODEL	DESCRIPTION	POWER SUPPLY
	Compatible with DOX and DOMIX 25/30/45.	
AT EASY_6	Water distributor to serve 6 dough- mixers, with 1/2" S.V. and 16mm hydraulic connections. Compatible with DOX and DOMIX 25/30/45.	115V/230V
AT MEDIUM_2	Water distributor to serve 2 dough- mixers, with 1/2" S.V. and 22mm hydraulic connections. Compatible with DOMIX 60/TriDOMIX 50.	115V/230V
AT MEDIUM_4	Water distributor to serve 4 dough- mixers, with 1/2" S.V. and 22mm hydraulic connections. Compatible with DOMIX 60/TriDOMIX 50.	115V/230V
AT MEDIUM_6	Water distributor to serve 6 dough- mixers, with 1/2" S.V. and 22mm hydraulic connections. Compatible with DOMIX 60/TriDOMIX 50.	115V/230V

MODEL	DESCRIPTION	POWER SUPPLY
AT LARGE_2	Water distributor to serve 2 dough-mixers, with 3/4" S.V. and 22mm hydraulic connections. Compatible with DOMIX 70/TriDOMIX 100.	115V/230V
AT LARGE_4	Water distributor to serve 4 dough-mixers, with 3/4" S.V. and 22mm hydraulic connections. Compatible with DOMIX 70/TriDOMIX 100.	115V/230V
AT LARGE_6	Water distributor to serve 6 dough-mixers, with 3/4" S.V. and 22mm hydraulic connections. Compatible with DOMIX 70/TriDOMIX 100	115V/230V
Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Благовещенск (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владикавказ (8672)28-90-48 Владимир (4922)49-43-18 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Курган (3522)50-90-47 Липецк (4742)52-20-81 Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Ноябрьск (3496)41-32-12 Новосибирск (383)227-86-73 Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37 Пермь (342)205-81-47 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Саранск (8342)22-96-24 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сургут (3462)77-98-35 Сыктывкар (8212)25-95-17 Тамбов (4752)50-40-97 Тверь (4822)63-31-35 Тольятти (8482)63-91-07 Томск (3822)98-41-53 Тула (4872)33-79-87 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Улан-Удэ (3012)59-97-51 Уфа (347)229-48-12 Хабаровск (4212)92-98-04 Чебоксары (8352)28-53-07 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Чита (3022)38-34-83 Якутск (4112)23-90-97 Ярославль (4852)69-52-93 Россия +7(495)268-04-70 Казахстан +7(7172)727-132 Киргизия +996(312)96-26-47		